










		YKH HIGH HEAT YKH MODULANT		
		1 kg	52 kg	53 kg
	#			
YKH	275	1861	650	2511
	300	1871	650	2521
	350	1901	650	2551



 ⇒ YKH = 12703193

	YKH 275-300-350 HIGH HEAT / MODULANT PLATE HEAT EXCHANGER	C	12703354	2 / 2
		Date : 28-JAN-2013		Rev : C
		 	Std	

ITEM	FRANCAIS	DEUTSCH	ENGLISH	ITEM	ITALIANO	NEDERLANDS	ESPAÑOL
(1)	POIDS DE L'UNITE ROOFTOP EN FONCTIONNEMENT (kg)	ROOFTOP BETRIBSGEWICHT (kg)	ROOFTOP UNIT WORKING WEIGHT (kg)	(1)	PESO DELL ROOFTOP UNITA IN FUNZIONE (kg)	ROOFTOP BEDRIJFSGEWICHT (kg)	ROOFTOP UNIDAD DE PESO EN OPERACION (kg)
(4)	SOUFFLAGE D'AIR EVAPORATEUR	VERDAMPFER LUFTAUSBLAS	SUPPLY OPENING	(4)	MANDATA ARIA	TOEVOERLUCHT	DESCARGA DE AIRE
(5)	REPRISE D'AIR EVAPORATEUR	VERDAMPFER RUECKLUFT	RETURN OPENING	(5)	REPRISA ARIA	RETOURLUCHT	RETORNO DE AIRE
(10)	BATTERIE CONDENSEUR	HITZUNG VERFLUSSIGER	CONDENSER COIL	(10)	BATTERIA CONDENSATORE	WARMTEWISSELAAR	BATERIA CONDENSADOR
(11)	AIRE NECESSAIRE POUR SORTIE D'AIR CONDENSEUR	MINDEST WANDABSTAND LUFTAUSTRITT	MINIMUM CLEARANCE AIR OUTLET	(11)	SPAZIO RICHIESTO PER ARIA IN USCITA	MINIMALE VRIJE RUIMTE VOOR LUCHTUITLATT	ESPACIO LIBRE MINIMO PARA SALIDA DE AIRE
(12)	AIRE NECESSAIRE POUR ENTREE D'AIR CONDENSEUR	MINDEST WANDABSTAND LUFTEINTRITT	MINIMUM CLEARANCE AIR INLET	(12)	SPAZIO RICHIESTO PER ARIA ENTRATA	MINIMALE VRIJE RUIMTE VOOR LUCHTINLATT	ESPACIO LIBRE MINIMO PARA TOME DE AIRE
(13)	AIRE CONSEILLEE POUR MAINTENANCE	MINDEST WANDABSTAND ZUR WARTUNG	MINIMUM CLEARANCE FOR MAINTENANCE	(13)	SPAZIO RICHIESTO PER MANUTENZIONE	MINIMALE VRIJE RUIMTE VOOR ONDERHOUD	ESPACIO LIBRE MINIMO PARA MANTENIMIENTO
(17)	TROUS DE LEVAGE	LOECHER FÜR HEBEZEUG	LIFTING HOLES	(17)	PUNTI DI SOLLEVAMENTO	HJSPUNTEN	PUNTO DE ELEVACION
(22)	AIR FRAIS	FRISCHLUFTH	FRESH AIR	(22)	PROTEZIONE (RIPRESA ARIA ESTERNA)	BUITENLUCHT	AIRE FRESCO
(50)	PHE MODULE	PHE MODULE	PHE MODULE	(50)	PHE MODULO	PHE MODULE	MODULO PHE
(52)	POIDS DU MODULE PHE EN FONCTIONNEMENT (kg)	PHE MODULE BETRIBSGEWICHT (kg)	PHE MODULE WORKING WEIGHT (kg)	(52)	PESO DELL PHE MODULO IN FUNZIONE (kg)	PHE MODULE BEDRIJFSGEWICHT (kg)	MODULO PHE DE PESO EN OPERACION (kg)
(53)	POIDS DE L'UNITE EN FONCTIONNEMENT (kg)	BETRIBSGEWICHT (kg)	UNIT WORKING WEIGHT (kg)	(53)	PESO DELL UNITA IN FUNZIONE (kg)	BEDRIJFSGEWICHT (kg)	PESO EN OPERACION (kg)
(54)	HOTTE D'EXTRACTION	DUNSTABZUGSHAUBE	EXHAUST HOOD	(54)	CAPP DI TORE ESPULSIONE	DAMPKAP	CAMPANA DE ESCAPE
	ENTREE D'AIR SORTIE D'AIR	LUFTEINTRITT LUFTAUSTRITT	AIR ENTRY AIR EXHAUST		ENTRATA ARIA USCITA ARIA	LUCHTINLAAT LUCHTUITLAAT	ENTRADA DE AIRE SALIDA DE AIRE